


A woman with extensive tattoos on her arms and hands is being embraced from behind. She is wearing a large, ornate earring and several rings. The background is dark with some green foliage. The entire scene is framed by a white border.

PREempt®

Strong but Gentle  
Professional Disinfectants  
for Spas & Salons

SURFACES | TOOLS | FOOT BATHS

Developed and Manufactured in Canada 

# 5-Minute High Level Disinfectant for Professional Tools

PREempt HLD5 is for professional nail tools (clippers, scissors, etc.)\*

- High level disinfects tools in just 5 minutes
- Ready to use (no mixing or diluting required)
- Re-use in a tool soaker for up to 14 days
- Odourless / No VOCs
- Biodegradable for easy, guilt-free disposal



# 20-Minute Chemosterilant for Professional Tools

PREempt CS20 is for professional nail tools (clippers, scissors, reusable foot files, etc.)\*

- Sterilizes tools in 20 minutes
- Ready to use (no mixing or diluting required)
- Re-use in a tool soaker for up to 14 days
- Odourless / No VOCs
- Biodegradable for easy disposal



*\*Do not use with soft metals such as nickel, brass or anodized aluminum*

# Ready to Use

## Surface Cleaner & Disinfectant



PREempt RTU is designed to clean and disinfect surfaces and non-circulating foot baths.

- 30 second broad-spectrum sanitizer
- 3 minute bactericide, virucide, fungicide, tuberculocidal
- Ideal for work tables, chairs, mag lamps, pedicure stools, basin foot baths or non-circulating foot baths, etc.
- Non-irritating to skin (does not require use of gloves)
- Ecologo certified (*RTU Liquid*)

# Concentrate

## for Circulating Foot Baths



PREempt Concentrate is a cleaner and disinfectant for circulating or “piped” foot baths. (Dilute 1:40)

- 30 Second Broad Spectrum Sanitizer
- 5 minute bactericidal, virucidal, fungicidal, tuberculocidal
- Ideal for disinfection between every client
- Removes and prevents the formation of biofilm
- Ecologo certified

# PREempt™ Reference Guide

WHERE TO USE	PRODUCT	HOW TO USE
<h2>Surfaces</h2>		
<ul style="list-style-type: none"> <li>Stainless Steel Bowls</li> <li>Non-Circulating (pipeless) Foot Baths</li> <li>Manicure Tables</li> <li>Magnifying Lamps</li> <li>Dryers</li> <li>Pedicure Foot Rests</li> <li>Esthetic Beds</li> <li>Reception Areas</li> </ul>	<p><b>PREempt Ready To Use Liquid</b></p> <ul style="list-style-type: none"> <li>1 Litre (sprayer available)</li> <li>4 Litre</li> </ul> <p><b>PREempt Wipes</b></p> <ul style="list-style-type: none"> <li>6" x 7" (160 ct)</li> </ul>	<p><b>Cleaning/Sanitizing (30 Seconds)</b></p> <ul style="list-style-type: none"> <li>Spray/wipe surface and using scrubbing action, physically remove debris</li> <li>Wipe and dry surface with a clean paper towel</li> </ul> <p><b>Disinfecting (3 minutes)</b></p> <ul style="list-style-type: none"> <li>Spray/wipe and leave surface wet for 3 minutes</li> <li>Allow to air dry or wipe with a clean paper towel</li> </ul> <p><b>Non-Circulating Foot Baths (between each client)</b></p> <ul style="list-style-type: none"> <li>Spray/wipe surface and bowl</li> <li>Using scrubbing action, physically remove debris</li> <li>Rinse with clean water</li> <li>Spray/wipe surface, bowl and leave wet for 3 minutes</li> <li>Rinse with clean water</li> </ul>
<h2>Professional Tools</h2>		
<ul style="list-style-type: none"> <li>Nail Nippers</li> <li>Cuticle Scissors / Pushers</li> <li>Tweezers</li> <li>Comedone Extractors</li> <li>Metal Foot Files</li> </ul>	<p><b>PREempt HLD5 Ready To Use</b> (14 day re-use in soaker)</p> <ul style="list-style-type: none"> <li>4 Litre</li> </ul>	<p><b>High Level Disinfection (after every client)</b></p> <ul style="list-style-type: none"> <li>Pre-clean, rinse, &amp; dry instruments and place them in tool soaker containing PREempt HLD5</li> <li>Let soak for 5 minutes, remove, rinse and dry thoroughly</li> <li>Store in sealed container marked "Disinfected" until use</li> </ul>
<p>Not for use on: Soft metals such as Nickel, Plated Brass and Anodized Aluminum</p>	<p><b>PREempt CS20 Ready To Use</b> (14 day re-use in soaker)</p> <ul style="list-style-type: none"> <li>1 Litre</li> <li>4 Litre</li> </ul>	<p><b>Sterilization (after every client)</b></p> <ul style="list-style-type: none"> <li>Pre-clean, rinse, &amp; dry instruments and place them in tool soaker containing PREempt CS20</li> <li>Let soak for 20 minutes, remove, rinse and dry thoroughly</li> <li>Store in sealed container marked "Disinfected" until use</li> </ul>
<h2>Circulating Foot Baths</h2>		
<ul style="list-style-type: none"> <li>Pedicure Chairs with internal circulating jets and piping</li> </ul>	<p><b>PREempt Concentrate Diluted 1:40</b></p> <ul style="list-style-type: none"> <li>4 Litre (pump available)</li> </ul>	<p><b>Disinfecting (between each client)</b></p> <ul style="list-style-type: none"> <li>Fill tub above jets with cool water and add approximately 400ml of PREempt Concentrate (for an average size circulating foot bath)</li> <li>Turn on jets and circulate for 5 minutes</li> <li>Drain and Rinse with water</li> </ul>

Available at professional beauty supply stores across Canada.  
For more information and printable directions, visit: [viroxprobeauty.ca](http://viroxprobeauty.ca)